

**important**  
note your personal  
combinations here

## **march** TSA fixed combination lock instructions

TSA locks are delivered without a key.  
Only TSA authorities have this.




reset button



TSA locks are recognizable  
when this logo is present

The keylock has been designed to comply with TSA regulations, and can be safely opened by use of a special key issued to TSA authorized personnel only.



Please check the proper operation of your TSA approved lock prior to changing the factory preset combination by making sure that the opening slide can freely travel only when the dials are set to “0-0-0”. To change to your own 3-digit combination, enter the current combination (0-0-0 for initial use) and follow the instructions below.

**1**

Using a pen tool, depress the small reset button **[1]** until you hear a “click” sound.

**2**

Rotate the dials **[2]** to select your new desired combination.

**3**

Your lock is now set to the combination showing when you released the reset button. **For other TSA models than illustration**, after step 1 and 2 push the main button **[A]** and let reset button slide back till you hear the “Click” sound.

**4**

To change to another combination, enter the current combination and repeat steps 1-3. This lock has been designed to comply with TSA regulations, and can be safely opened by correct entry of the combination or by use of a special key issued to TSA authorized personnel only.